


|


BOSTITCH®

|

MODEL 19E
WIRE STITCHER




OPERATION
and MAINTENANCE
MANUAL



15001D HEAD


NO. 14 BOSTITCH BOX STITCHER



15001D HEAD




NO. 15 BOSTITCH BOX STITCHER




15001D HEAD

NO. 14B BOSTITCH BOTTOMING STITCHER




19001E HEAD

NO. 19E BOSTITCH SINGLE STITCHER




18001D HEAD

NO. 18 BOSTITCH MULTIPLE STITCHER



18001D27 HEAD



NO. 27 BOSTITCH MULTIPLE STITCHER

Bostitch Stitchers Using No. 15001D, 18001D, 18001D27, or 19001E Heads

INSTALLATION, OPERATION AND MAINTENANCE

of

No. 19E BOSTITCH STITCHER WITH No. 19001E HEAD

CAPACITY: 9/16 "

SIZE OF WIRE: No. 19x21½, 20x24 and 21x25 Flat
No. 20, 23 and 25 thru 30 Round

CROWN OR STAPLE WIDTH: ⅜", ½" (Standard), ⅝" and ¾"

SPEED: Up to 300 stitches per minute

Note: This book does not include head instructions. It should be used in conjunction
with

"Bostitch Model 19001E Wire Stitcher Head Operation and Maintenance Manual"

1. INTRODUCTION

To obtain satisfactory results from a wire stitcher, as with any other machine, it is necessary that it be properly installed and adjusted, regularly lubricated and carefully maintained.

In case of any serious trouble, however, you should notify the nearest sales office, sending samples of the defective work and describing the trouble in detail, so as to obtain the benefit of their experience in arriving at the proper solution. Be sure to report the serial number and model of the machine when corresponding in regard to it, so that it may be quickly identified.

2. INSTALLATION

To prevent damaging the machine during its installation, we recommend that the following procedure be closely followed:

- a. After uncrating machine, examine carefully for any breakage in transit. If such is found, do not attempt to run machine but report at once to the selling agent. If service man is present, let him examine machine carefully and then report to manufacturer.
- b. Examine name plate on motor and see that its specifications are the same as those of the power to be used. If not, do not attempt to use.
- c. Since each machine is shipped with some parts disassembled, it is necessary that these parts be reassembled onto the machine.

Attach spool stud and disc, wire guide spring, adjusting screw crank arm, motor bracket, motor, V-belts, belt shield, belt guard and table.

The mounting of motor onto the base is a simple matter which needs no explanation. When assembling belts, make sure that they are only tight enough to run machine without slippage. Belt tension may be adjusted by moving motor bracket up or down.

- d. Place machine on level floor, using shims under base to prevent any movement or rocking.
- e. Lubricate machine thoroughly as described in head instructions and as follows: Apply generous supply of oil (S.A.E. 10) to pulley washer as this lubricates clutch. Oil drive shaft through oil cups (2) at top of frame and oil universal joints in drive shaft through large holes (2) in left side of frame. Oil cam roll at upper end of clincher cam slide at rear of machine.
- f. Trip the clutch by means of the movable foot pedal at front of machine and turn machine over by hand a few times to see that everything is clear.

Then take foot off clutch trip pedal and rotate clutch pulley rapidly, so that clutch will be entirely disengaged. Do not turn electric switch on until pulley rotates freely.

- g. Connect motor cord to power outlet and start motor. See that large pulley or flywheel turns in direction of arrow cast on pulley, or clockwise as viewed from the front of the machine. Should it rotate counterclockwise, motor wiring should be reconnected by electrician in order to reverse direction of rotation.

- h. If rotation is correct, push down on foot pedal and start machine operating. Remove foot from pedal and machine will stop. A very little practice will enable operator to know exactly how to stop and start machine exactly when desired.

3. OPERATION

- a. Place a spool of wire of the proper size on the spool holder located near the stitching mechanism or head.

When loading with wire wound on paper cores: Remove detachable flange from spool and insert coil of wire, replacing flange and turning coil till binding wires are aligned with slots in flanges. Tighten nut till coil is snugly held. Cut binding wires, except the one holding the end of the coil. (They may be pulled out through the slots.) Then grasp, end of coil and cut and remove the binding wire which holds it. Thread the machine as described in head instructions.

- b. Referring to head operating adjustments instructions, follow procedure for remainder of operations required, such as wire straightening and adjustment for length of wire.

Gauge for thickness by placing work under gauge at left of head and adjust crank at right of head until work is tightly pinched under gauge. After turning pulley by hand once so as to be sure that machine is properly set for thickness to be stitched, power can be applied.

Clinchers can be adjusted for tight or loose clinch by means of screw at back of clincher operating lever, first releasing the binder screw. A slight turn will make considerable difference in the operation of the clinchers.

- c. Machine is now ready to do stitching and with directions as outlined above satisfactory results should be obtained. Make several rows of stitches in stock to be used, examining crown and legs for proper appearance. If not satisfactory, adjust machine in accordance with directions given below. See section 4 "Appearance of Stitches" and "Trouble Shooting Chart" in head instructions.


d. CAUTION: - Never operate machine with wire feeding and no stock above clinchers. Serious damage may result if this practice is followed.

4. APPEARANCE OF STITCHES

If stitching is defective, compare stitch produced with illustrations in head instruction manual. To

eliminate defect, follow instructions given with illustration that agrees with defect. If it is necessary to correspond about any defective stitches or other difficulties with the machine, be sure to refer by letter to the illustration in head instructions book, which shows the type of stitch defect and, if possible, send a sample of the work actually being done on the machine.

To align clincher with wire grooves: If stitch is rolled (in thin work), clincher is out of line with wire grooves. Remedy: - Realign same. This is normally a factory adjustment and should never be disturbed unless you are convinced that it must be done to rectify trouble as itemized. This adjustment can be made by means of adjusting screws "B" located in frame near bottom of head as shown below. Loosening bonnet binder screw "A" and turning screws "B", head can be moved forward or back as desired. Be sure to lock screw "A" tightly after re-adjustment is made.



5. *THE ESSENTIAL POINTS OF STITCHING

In order to continue to obtain satisfactory stitches it is necessary that the following essentials be observed:

- a. The legs of the staple must be of the same length.
- b. Wire must enter cutters as nearly straight as possible.
- c. The cutters or knives must be sharp and properly set so that there are no burrs on end of wire and wire is cut with a square end (not beveled).
- d. The clinchers must work freely and be in good condition mechanically, with no pitted or badly worn grooves. Head must be adjusted for proper compression of work to be stitched.
- e. The machine must be kept clean and properly oiled.
- f. The wire must be of the correct size for stock to be stitched and must be used only in the proper bender bar. Wire fitting the bender bar grooves too loosely will cause buckling, and too large a wire will also cause buckling in addition to excess wear on the bender bars. Be guided by the operating instructions for the proper size wire.
- g. The wire spool must be free to turn and the wire must not be allowed to become crossed. Short staples and even entire failure to produce staples may result from crossed or tangled wires.

- h. Stitcher must be equipped with proper clincher points for either round or flat wire depending on wire being used.

*The necessary adjustments, replacements, etc. required to meet conditions as listed above are described in detail in the head and stitcher instructions.


6. MAINTENANCE

- a. Machine should be lubricated regularly as described under heading of "Installation" in this pamphlet and under heading of "Maintenance" in head instructions.
- b. The friction clutch is adjusted by means of screw 2340B in brake band 2339A. Screw in if clutch slips. Screw out if clutch knocks. A quarter turn will make considerable difference in action of the clutch.
- c. Removal and replacement of clinchers. To remove clinchers, release clincher slide 19184B from slide bar 19186 by removing screw 9044B.


Hold slide when releasing screw, to prevent slide from dropping into base of machine. Lower slide enough to disengage clinchers, which can then be raised to vertical position and removed through upper opening in clincher plate.

To replace clinchers, push down as far as they will go into clincher plate, so that lip on slide will enter notch in clincher. Align hole in slide with that in slide bar and replace screw.

To assure good stitching, clinchers should be kept free from dirt and particles of wire.



STITCHER COMPONENT PARTS - SHEET 1



STITCHER COMPONENT PARTS - SHEET 2

PARTS LIST

Index No.	Name of Part	Part No.	Index No.	Name of Part	Part No.
1	Driving Pulley	2331B	44	Adjusting Link Spring Pin	406
2	Clutch Ring	2332BA	45	Bonnet Screw	15002
3	Clutch Ring Expanding Pin	2347	46	Adjusting Link Spring	14280
4	Brake Band Adjusting Screw Lock	2341	47	Thickness Gage Seat	19296
5	Brake Band Adjusting Screw Lock Spring	9051	48	Thickness Gage Seat Binder	UA5806.1
6	Brake Band Adjusting Screw	2340B	49	Bonnet Aligning Screw	2287
7	Brake Band Assembly	2339A	50	Clutch Shaft Assembly	19314A
8	Brake Band Pin	2344	51	Adjusting Screw Washer - Small	19276
9	Clincher Cam	19244	52	Adjusting Screw Crank Arm	19278A
10	Clutch Pawl	2337	53	Adjusting Screw Crank Retaining Washer	19280
11	Clutch Lever Pivot Pin	2334	54	Adjusting Screw Crank Retaining Screw	9044B
12	Clutch Lever Spring	2335	55	Adjusting Screw Bushing	14272
13	Clutch Lever Spring Plunger	2336	56	Adjusting Bearing Pivot Set Screw	UA5804.1
14	Clutch Lever	2333	57	Adjusting Bearing Pivot Set Screw	UA5806.1
15	Clutch Pawl Plunger	347	58	Adjusting Nut Stop	14284
16	Brake Band Link	19242	59	Clutch Shaft Key	66B
17	Driving Pulley Washer Oiler	85221	60	Intermediate Shaft Joint Pin	19311
18	Driving Pulley Washer Screw	2349	61	Intermediate Shaft Joint	19310
19	Driving Pulley Washer Assembly	2217DA	62	Intermediate Shaft Joint Shim	19312
20	Driving Pulley Washer Screw Lock	2350	63	Intermediate Shaft	19309
21	Driving Pulley Washer Screw Lock Spring	030	64	Adjusting Nut	14282
22	Driving Pulley Washer Set Screw	UA5804.1	65	Adjusting Bearing Pivot	14277
23	Belt Guard Screw	UA7116.2	66	Adjusting Nut Connecting Pin	14283
24	Belt Guard Washer	PW716	67	Adjusting Bearing	14276A
25	Belt Guard	2359	68	Adjusting Bearing Bushing	19269
26	Stop Plunger Spring	19238	69	Adjusting Link Spring Pin	406
27	Stop Plunger	19237	70	Adjusting Link Spring Pin Lock Washer	LW516
28	Stop Plunger Lever	2226C	71	Thickness Gage Stud	19293
29	Belt Guard Bracket	2358	72	Thickness Gage	19292
30	Belt Guard Bracket Screw	UA7120.2	73	Thickness Gage Stud Nut	HN51618
31	Belt Shield	2356	74	Adjusting Link	14278
32	Belt Shield Washer	PW716.2	75	Adjusting Link Pin	14279
33	Belt Shield Screw	UA7116.2	76	Crank Shaft Assembly	19301A
34	Clincher Operating Lever Spring	E183B	77	Bender Link Assembly	19283A
35	Frame	19201B	78	Crank Pin Roll	19306
36	Base	19204	79	Crank Pin Roll Stud	19307
37	Frame Screw	7018	80	Connecting Pin Washer	2228
38	Bushing	148H	81	Driver Link Connecting Pin	15287
39	Adjusting Screw	19273	82	Connecting Pin Washer	2228
40	Adjusting Screw Washer - Large	19275	83	Bender Link Connecting Pin	15286
41	Adjusting Screw Pin	19277	84	Table Support Bracket	7645A
42	Adjusting Screw Catch Spring	461	85	Table Support Bracket Screw	UA5116.1
43	Adjusting Screw Catch	19274			

PARTS LIST (continued)

Index No.	Name of Part	Part No.	Index No.	Name of Part	Part No.
86	Work Table Adjusting Screw - Saddle Position	UA4828.3	125	Treadle Connection Lever Bracket	19230
87	Work Table Adjusting Screw - Flat Position	UA4820.3	126	Treadle Connection Lever	19228
88	Work Table Position Adjusting Screw Nut	HN1420.2	127	Treadle Connection	19225
89	Work Table Position Adjusting Screw Nut	HN1420.2	128	Treadle Connection Lever Pivot	19229
90	Table Support Bracket Nut	HN51618.2	129	Treadle Connection Spring	14
91	Bonnet Guard - Left	19006	130	Foot Rest	2289
92	Bonnet Guard - Right	19005	131	Foot Rest Set Screw	UA5812.2
93	Bonnet Guard Screw	UA4812.5	132	Intermediate Lever	19233
94	Oil Cup	85202	133	Treadle	19217
95	Brake Band Link Stud	2343	134	Treadle Shaft	19221
96	Clincher Cam Slide Strap Screw	UA3308.2	135	Treadle Shaft Cotter Pin	UB3916.1
97	Clincher Cam Slide Strap Screw Lock Washer	LW10	136	Clincher Slide Bar Retaining Screw	UA4824.3
98	Clincher Cam Slide Strap	2345	137	Clincher Slide Bar Retaining Screw Lock Nut	HN1420
99	Stop Plunger Lever Pivot	UB6144	138	Work Stop Screw	425
100	V-Belt	2290B	139	Work Stop - Right	7423
101	Motor Pulley (For 230 SPM) St'd	19325EA	140	Work Stop - Left	7424
102	Motor Pulley Set Screw	UA5806.1	141	Work Guide	7201
103	Clincher Cam Roll	48	142	Work Guide Binder Screw	7063
104	Clincher Cam Roll Stud	49	143	Work Table	7656A
105	Clincher Cam Slide Stop Screw	UA6805	144	Table Support Stud	7655
106	Clincher Cam Slide	19246A	145	Table Support Spring	B554
107	Stop Plunger Connection	19241	146	Table Support	7648
108	Motor Bolt and Nut	2301	147	Work Table Swivel Pin Screw	38
109	Motor Bolt Washer	PW14	148	Table Support Stud Washer	PW10
110	Motor Bracket	16010	149	Table Support Stud Nut	HN1032
111	Motor Bracket Screw	UA6124.1	150	Work Table Swivel Pin	203B
112	Motor Bracket Washer	PW38	151	Work Table Extension - Front	7056
113	Clincher Operating Lever Screw Binder	38	152	Work Table Extension Screw	425
114	Clincher Operating Lever Screw	UA5520.1	153	Work Table Extension - Back	53
115	Clincher Operating Lever	19251	154	Work Table Extension Screw	59
116	Clincher Operating Lever Pivot	19254	155	Clincher Plate Assembly	7253EA
117	Clincher Operating Lever Pivot Collar	2238	156	Clincher Pivot Stud	7258
118	Clincher Operating Lever Pivot Screw	0053	157	Clincher Plate Distance Stud	7259
119	Intermediate Lever Pivot	19240	158	Clincher Guide Plate	7254D
120	Treadle Connection Lever Bracket Nut	5026	159	Clincher Slide Strap	7256
121	Treadle Connection Lever Bracket Washer	PW38	160	Clincher Slide Strap Rivet	7260
122	Clincher Slide Bar	19186	161	Clincher Point - Round Wire	7257C
123	Clincher Operating Lever Pin	2293	162	Clincher Point - Flat Wire	7024D
124	Treadle Connection Lever Bracket Collar	2238	163	Clincher Plate Screw	341
			164	Clincher Plate Dowel	29
			165	Clincher Slide	19184B
			166	Clincher Slide Screw	9044B
				Motor Starter Heater	
				(Specify Amperage of Motor)	

NUMERICAL INDEX

Part Number	Name	Index Number	Part Number	Name	Index Number
0053	Clincher Operating Lever	118	2345	Clincher Cam Slide Strap	98
	Pivot Screw	118	2347	Clutch Ring Expanding Pin	3
030	Drive Pulley Washer Screw		2349	Driving Pulley Washer Screw	18
	Lock Spring	21	2350	Driving Pulley Washer Screw	
14	Treadle Connection Spring	129		Lock	20
29	Clincher Plate Dowel	163	2356	Belt Shield	31
38	Clincher Operating Lever		2358	Belt Guard Bracket	29
	Screw Binder	113	2359	Belt Guard	25
38	Work Table Swivel - Pin		5026	Treadle Connection Lever	
	Screw	147		Bracket Nut	120
48	Clincher Cam Roll	103	7018	Frame Screw	37
49	Clincher Cam Roll Stud	104	7024D	Clincher Point - Flat Wire	161
53	Work Table Extension - Back	153	7056	Work Table Extension - Front	151
59	Work Table Extension Screw	154	7063	Work Guide Binder Screw	142
66B	Clutch Shaft Key	59	7201	Work Guide	141
148H	Bushing	38	7253EA	Clincher Plate Assembly	155
203B	Work Table Swivel Pin	150	7254D	Clincher Guide Plate	158
341	Clincher Plate Screw	162	7256	Clincher Slide Strap	159
347	Clutch Pawl Plunger	15	7257C	Clincher Point - Round Wire	161
406	Adjusting Link Spring Pin	44	7258	Clincher Pivot Stud	156
406	Adjusting Link Spring Pin	69	7259	Clincher Plate Distance	
425	Work Stop Screw	138		Stud	157
425	Work Table Extension Screw	152	7260	Clincher Slide Strap Rivet	160
461	Adjusting Screw Catch Spring	42	7423	Work Stop - Right	139
2217DA	Drive Pulley Washer Assembly	19	7424	Work Stop - Left	140
2226C	Stop Plunger Lever	28	7645A	Table Support Bracket	84
2228	Connecting Pin Washer	80	7648	Table Support	146
2228	Connecting Pin Washer	82	7655	Table Support Stud	144
2238	Clincher Operating Lever Pivot		7656A	Work Table	143
	Collar	117	9044B	Adjusting Screw Crank	
2238	Treadle Connection Lever			Retaining Screw	54
	Bracket Collar	124	9044B	Clincher Slide Screw	165
2287	Bonnet Aligning Screw	49	9051	Brake Band Adjusting Screw	
2289	Foot Rest	130		Lock Spring	5
2290B	V Belt	100	14272	Adjusting Screw Bushing	55
2293	Clincher Operating Lever		14276A	Adjusting Bearing	67
	Pin	123	14277	Adjusting Bearing Pivot	65
2301	Motor Bolt and Nut	108	14278	Adjusting Link	74
2331B	Driving Pulley	1	14279	Adjusting Link Pin	75
2332BA	Clutch Ring	2	14280	Adjusting Link Spring	46
2333	Clutch Lever	14	14282	Adjusting Nut	64
2334	Clutch Lever Pivot Pin	11	14283	Adjusting Nut Connecting Pin	66
2335	Clutch Lever Spring	12	14284	Adjusting Nut Stop	58
2336	Clutch Lever Spring Plunger	13	15002	Bonnet Screw	45
2337	Clutch Pawl	10	15286	Bender Link Connecting Pin	83
2339A	Brake Band Assembly	7	15287	Driver Link Connecting Pin	81
2340B	Brake Band Adjusting Screw	6	16010	Motor Bracket	110
2341	Brake Band Adjusting Screw		19005	Bonnet Guard - Right	92
	Lock	4	19006	Bonnet Guard - Left	91
2343	Brake Band Link Stud	95	19184B	Clincher Slide	164
2344	Brake Band Pin	8	19186	Clincher Slide Bar	122

NUMERICAL INDEX (continued)

Part Number	Name	Index Number	Part Number	Name	Index Number
19201B	Frame	35	LW10	Clincher Cam Slide Strap	
19204	Base	36		Screw Lock Washer	97
19217	Treadle	133	LW516	Adjusting Link Spring Pin	
19221	Treadle Shaft	134		Lock Washer	70
19225	Treadle Connection	127	PW10.	Table Support Stud Washer	148
19228	Treadle Connection Lever	126	PW14	Motor Bolt Washer	109
19229	Treadle Connection Lever		PW38	Motor Bracket Washer	112
	Pivot	128	PW38	Treadle Connection Lever	
19230	Treadle Connection Lever			Bracket Washer	121
	Bracket	125	PW716	Belt Guard Washer	24
19233	Intermediate Lever	132	PW716.2	Belt Shield Washer	32
19237	Stop Plunger	27	HN1032	Table Support Stud Nut	149
19238	Stop Plunger Spring	26	HN1420	Clincher Slide Bar Retaining	
19240	Intermediate Lever Pivot	119		Screw Lock Nut	137
19241	Stop Plunger Connection	107	HN1420.2	Work Table Position Adj.	
19242	Brake Band Link	16		Screw Nut	88
19244	Clincher Cam	9	HN1420.2	Work Table Position Adj.	
19246A	Clincher Cam Slide	106		Screw Nut	89
19251	Clincher Operating Lever	115	HN51618	Thickness Gage Stud Nut	73
19254	Clincher Operating Lever		HN51618.2	Table Support Bracket Nut	90
	Pivot	116	UA3308.2	Clincher Cam Slide Strap	
19269	Adjusting Bearing Bushing	68		Screw	96
19273	Adjusting Screw	39	UA4812.5	Bonnet Guard Screw	93
19274	Adjusting Screw Catch	43	UA4820.3	Work Table Adjusting Screw-	
19275	Adjusting Screw Washer -			Flat Position	87
	Large	40	UA4824.3	Clincher Slide Bar Retaining	
19276	Adjusting Screw Washer -			Screw	136
	Small	51	UA4828.3	Work Table Adjusting Screw-	
19277	Adjusting Screw Pin	41		Saddle Position	86
19278A	Adjusting Screw Crank Arm	52	UA5116.1	Table Support Bracket Screw	85
19280	Adjusting Screw Crank		UA5520.1	Clincher Operating Lever	
	Retaining Washer	53		Screw	114
19283A	Bender Link Assembly	77	UA5804.1	Driving Pulley Washer Set	
19292	Thickness Gage	72		Screw	22
19293	Thickness Gage Stud	71	UA5804.1	Adjusting Bearing Pivot Set	
19296	Thickness Gage Seat	47		Screw	56
19301A	Crank Shaft Assembly	76	UA5806.1	Thickness Gage Seat Binder	48
19306	Crank Pin Roll	78	UA5806.1	Adjusting Bearing Pivot Set	
19307	Crank Pin Roll Stud	79		Screw	57
19309	Intermediate Shaft	63	UA5806.1	Motor Pulley Set Screw	102
19310	Intermediate Shaft Joint	61	UA5812.2	Foot Rest Set Screw	131
19311	Intermediate Shaft Joint Pin	60	UA6124.1	Motor Bracket Screw	111
19312	Intermediate Shaft Joint Shim	62	UA6805	Clincher Cam Slide Stop	
19314A	Clutch Shaft Assembly	50		Screw	105
19325EA	Motor Pulley	101	UA7116.2	Belt Guard Screw	23
85202	Oil Cup	94	UA7116.2	Belt Shield Screw	33
85221	Driving Pulley Washer Oiler	17	UA7120.1	Belt Guard Bracket Screw	30
B554	Table Support Spring	145	UB3916.1	Treadle Shaft Cotter Pin	135
E183B	Clincher Operating Lever		UB6144	Stop Plunger Lever Pivot	99
	Spring	34			